

Service Bulletin

SF-036

DATE: July 12, 2010
TO: All Service and Parts Managers
SUBJECT: Low Voltage Board Connectors

The communicating controls in Goodman's Furnaces, Split Condensers, Heat Pumps and Air-Handlers are shipped with the required Phoenix connectors needed for connecting the low voltage wiring to these units. However we understand these connectors can from time to time get misplaced preventing you from completing the installation; therefore we have made these connectors available through service parts.

Please refer to the following list for part numbers when ordering connectors;

Furnace and Air-Handler 9 pin connector: # F043067300S
Split Condenser or Heat Pump 7 pin connector: # F043067500S
Communicating mode 4 pin connector: # F043067900S



These connectors are in stock and available from Goodman Service Parts.



Technical Services Department • 1810 Wilson Parkway • Fayetteville, TN 37334
Main: 888.593.9988 • Service Fax: 713.316.5541