

TRANQUILITY 27 (TTV SERIES)

	TTV026	TTV038	TTV049	TTV064	TTV072
ECM Motor Assembly with Controller	S14S0016N04	S14S0016N03	S14S0016N02	S14S0016N01	S14S0017N17
CXM Controller Service Pack	S17B0001N01	S17B0001N01	S17B0001N01	S17B0001N01	S17B0001N01
Control Board ECM	17B0034N02	17B0034N01	17B0034N01	17B0034N01	17B0034N01
Capacitor	15B0013N13(35/370)	15B0013N14(40/370)	15B0013N15(45/370)	15B0013N20(80/370)	15B0013N20(80/370)
Transformer	15B0002N02	15B0002N02	15B0002N02	15B0002N02	15B0002N02
Kit, Thermistor Gray 36 Inch	S17S0030N01	S17S0030N01	S17S0030N01	S17S0030N01	S17S0030N01
Kit, Thermistor Violet FP2 48 Inch	S17S0031N01	S17S0031N01	S17S0031N01	S17S0031N01	S17S0031N01
Expansion Valve	33B0013N01	33B0013N02	33B0013N02	33B0013N02	33B0015N02
Reversing Valve with Solenoid	S69173500	S69172601	S69172601	S69172601	S69172601
Filter MERV11 Pleated	76B0005N14(24X28X2)	76B0005N15(28X30X2)	76B0005N19(30X32X2)	76B0005N20(30X36X2)	76B0005N20(30X36X2)
Blower Wheel 9x7	68624003				
Blower Housing Assembly with Wheel		73B0004N01	73B0004N01	73B0004N01	73B0004N01
HWG Pump 230V 5/8" Sweat	69178806	69178806	69178806	69178806	69178806

TRANQUILITY 27 (TTS SERIES)

	TTS026	TTS038	TTS049	TTS064
CXM Controller Service Pack	S17B0001N01	S17B0001N01	S17B0001N01	S17B0001N01
Capacitor	15B0013N13	15B0013N14	15B0013N15	15B0013N20
Kit, Thermistor Gray 36 Inch	S17S0030N01	S17S0030N01	S17S0030N01	S17S0030N01
Kit, Thermistor Violet FP2 48 Inch	S17S0031N01	S17S0031N01	S17S0031N01	S17S0031N01
Expansion Valve	33B0020N01	33B0020N02	33B0020N03	33B0020N04
Reversing Valve with Solenoid	S69173500	S69172601	S69172601	S69172601
HWG Pump 230V 5/8" Sweat	69178806	69178806	69178806	69178806

TRANQUILITY 27 (TTH SERIES)

	TTH026	TTH038	TTH049	TTH064	TTH072
ECM Motor Assembly with Controller	S14S0016N04	S14S0016N03	S14S0016N02	S14S0016N01	S14S0017N17
CXM Controller Service Pack	S17B0001N01	S17B0001N01	S17B0001N01	S17B0001N01	S17B0001N01
DWH/ECM Interface Board	17B0034N01	17B0034N01	17B0034N01	17B0034N02	17B0034N01
Transformer	15B0002N02	15B0002N02	15B0002N02	15B0002N02	15B0002N02
Capacitor	15B0013N13 (35/370)	15B0013N14 (40/370)	15B0013N15 (45/370)	15B0013N20 (80/370)	15B0013N20 (80/370)
Kit, Thermistor Gray 36 Inch	S17S0030N01	S17S0030N01	S17S0030N01	S17S0030N01	S17S0030N01
Kit, Thermistor Violet FP2 48 Inch	S17S0031N01	S17S0031N01	S17S0031N01	S17S0031N01	S17S0031N01
Expansion Valve	33B0013N01	33B0013N02	33B0013N02	33B0013N02	33B0015N02
Reversing Valve with Solenoid	S69173500	S69172601	S69172601	S69172601	S69172601
Filter MERV11 Pleated	76B0005N01 (18X18X2)	76B0005N02 (12X20X2)	76B0005N04 (18X20X2)	76B0005N07 (20X24X2)	76B0005N07 (20X24X2)
Filter MERV11 Pleated		76B0005N09 (20X25X2)	76B0005N07 (20X24X2)		
Blower Wheel ONLY	68624003				
Blower Housing Assembly with Wheel		73B0004N01	73B0004N01	73B0004N01	73B0004N01
HWG Pump 230V 5/8" Sweat	69178806	69178806	69178806	69178806	69178806

TRANQUILITY WATER- WATER (TMW)

	TMW036	TMW060	TMW120
CXM Controller Service Pack	S17B0001N01	S17B0001N01	S17B0001N01
ECM Interface Board	17B0034N01	17B0034N01	17B0034N01
Transformer	15B0002N02	15B0002N02	15B0002N02
Capacitor	15B0013N34 (45/440)	15B0013N20 (80/370)	15B0013N20 (80/370)
SOFT START Capacitor	15B0014N01 (90-277)		
Kit, Thermistor Gray	S17S0030N01	S17S0030N01	S17S0030N02
Kit, Thermistor Violet FP2	S17S0031N01	S17S0031N01	S17S0031N02
Expansion Valve	33B0043N01	33B0043N02	33B0043N02
Reversing Valve with Solenoid	S69173500	S69172601	S69172601
HWG Pump 230V 5/8" Sweat	69178806	69178806	69178806

TRANQUILITY AHU (TAH)

	TAH026	TAH038	TAH049	TAH064
ECM Motor Assembly with Controller	S14S0016N04	S14S0016N03	S14S0016N02	S14S0016N01
Control Board ECM2	17B0034N02	17B0034N02	17B0034N02	17B0034N02
Air Coil	61B0400N01	61B0401N01	61B0403N01	61B0404N01
Blower Housing Assembly with Wheel		73B0004N01	73B0004N01	73B0004N01
Blower Wheel ONLY	68624003			
Filter	68544402(20X20X1)	68544402(20X20X1)	68544402(20X20X1)	76B0001N07 (20X24X1)
Transformer	15B0002N09	15B0002N09	15B0002N09	15B0002N09
Kit, Thermistor Violet FP2	S17S0031N01	S17S0031N01	S17S0031N01	S17S0031N01

