

Goodman Heat Pump Master Stock List



Part Number	Description	Substitution
CAP050350440RSS	CAPACITOR 5/35/440V	
PCBHR102S	PCB, CONTROL, 2 STG, HP	PCBHR103S
0130M00053	OUTDOOR COIL TEMP SENSOR	
0130M00054	OUTDOOR AIR TEMP SENSOR	
CAP050400440RTS	CAPACITOR 5/40/440V	
CAP050450440RTS	CAPACITOR 5/45/440V	
CAP050800440RTS	CAPACITOR 5/80/440V	
B1370803	DEFROST THERMOSTAT	
CONT2P025024VS	CONTACTOR 25 AMP, 2P, 24V	
PCBDM133	DEFROST CONTROL BOARD	PCBDM133S
CONT2P030024VS	CONTACTOR 30 AMP, 2P, 24V	
CAP050300370RSS	CAPACITOR 5/30/370V	CAP050300440RSS
CAP050400370RSS	CAPACITOR 5/40/370V [CONTROL BOX]	CAP050400440RTS
CAP050450370RSS	CAPACITOR 5/45/370V [CONTROL BOX]	CAP050450440RTS
CAP050700370RTS	CAPACITOR 5/70/370V	CAP050700440RTS
CAP050300440RSS	CAPACITOR 5/30/370V	
0131M00060S	COND MOTOR 1/6 HP, 1 SP, 8 PL	
0131M00266	MOTOR, 1/8 HP 8 PL PSC	0131M00060S
0130M00085	DEFROST THERMOSTAT	
0131M00061S	COND MOTOR, 1/4HP, 1SP, 8PL	
CAP050000370VAS	CAPACITOR 5/370V	
CONT3P025024VS	CONTACTOR 25 AMP, 3P, 24V	
PCBDM130	DEFROST CONTROL BOARD	PCBDM101S
CAP050700440RTS	CAP, 5/70 MFD/440V/DUAL RD	